

H-150 panel piercing saw

Catalogue number 50128 (blade) and 50301 (handle). Previously 7011.

Japanese backsaw (DOZUKI) — Ideal for **intricate** and **precise** crosscut work on **veneer**, **laminated board**, **hardwood** and **softwood**.







SPECIFICATION

PITCH	BLADE		KERF	MAXIMUM CUTTING DEPTH
	LENGTH	THICKNESS		
1.41mm(18TPI)	150mm	0.3mm	0.49mm	38mm

FEATURES

- Special **piercing tooth** designed for cutting a slot in the centre of a board. A video demonstrating this can be seen at www.woodworkprojects.co.uk/Panel_Saw_demo.wmv.
- **38mm**-maximum cutting depth for wide-ranging cutting ability.
- Reinforced thin blade and perfectly ground teeth are ideal for fine detail cutting leaving an incredibly smooth cut surface.
- Easy blade replacement with one simple tap.

REPLACEMENT OF SAW BLADE

Detaching blade	Attaching blade
<ul style="list-style-type: none"> ● Tap the front edge on a small block of scrap timber to loosen the blade.  <ul style="list-style-type: none"> ● Pull the blade out of the spine. 	<ul style="list-style-type: none"> ● Hook the blade into the spine.  <ul style="list-style-type: none"> ● Tap the spine on a small block of scrap timber to attach the blade. 

CAUTION:

Since the saw teeth are very sharp, we recommend that you wear gloves or wrap the blade with something (a cloth or towel or its cardboard sleeve) when replacing the blade.

WARNING: Never use excessive force when tapping the blade or spine, as the blade may fly out and cause serious injury. With a little practice you will quickly learn the correct amount of force to use.