

H-210 Oricco

Part number 50221 (blade) and 50331 (handle). Was 15026.

Designed mainly for pruning trees, but can easily be used for conventional woodworking.





SPECIFICATION

PITCH	BLADE LENGTH	BLADE THICKNESS	KERF
2.3mm(11 TPI)	210mm	0.8mm	1.10mm

FEATURES

- Teflon-coated blade for smooth cutting, rust prevention, and clean cut surface.
- Easy blade replacement with one simple tap.
- Induction impulse hardened teeth for long-lasting great performance.
- Angle-adjustable handle for pruning trees in awkward and confined places.
- Folds to protect the blade when not in use.

REPLACEMENT OF SAW BLADE

Detaching blade	Attaching blade
<ul style="list-style-type: none">● Make sure the blade is locked, and then tap the back of the handle to detach the blade. 	<ul style="list-style-type: none">● Hook the blade into the spine and tap the handle to fix the blade. 

CAUTION:

Since the saw teeth are very sharp, we recommend that you wear gloves or wrap the blade with something (a cloth or towel or its cardboard sleeve) when replacing the blade.