

PS-170 pruning

Blade part number 50031, handle 50366. Previously 17108.

Aggressive saw teeth and robust blade are ideal for pruning fruit trees, and other green woods.




SPECIFICATION

PITCH	BLADE LENGTH	BLADE THICKNESS	KERF
2.15mm (11 TPI)	173mm	0.5mm	0.60mm

FEATURES

- High quality sharp teeth (impulse hardened) designed for long-lasting great performance.
- Interchangeable blade style saves you money.
- Narrow saw blade is ideal for pruning trees in awkward or confined places.
- Nickel-plated saw blade for rust prevention.
- Optional scabbard for protection and portability.

REPLACEMENT OF SAW BLADE



- Loosen the screw with coin or screwdriver, without removing it completely, and pull the blade out from the handle.
- Insert the blade, and tighten the screw to fix the blade firmly.

CAUTION:

Since the saw teeth are very sharp, we recommend that you wear gloves or wrap the blade with something (a cloth or towel or its cardboard sleeve) when replacing the blade.