

PS-230 pruning coarse

Catalogue 50100 (blade) and 50366 (handle). Was 17106.

Designed for pruning Deciduous Fruit Trees and other green wood.



SPECIFICATION


PITCH	BLADE LENGTH	BLADE THICKNESS	KERF
4mm (6 TPI)	230mm	0.8mm	1.02mm

FEATURES

- High quality sharp teeth (impulse hardened) designed for long-lasting great performance.
- Interchangeable blade style saves you money.
- Nickel-plated saw blade for rust prevention.
- Optional scabbard to protect the blade and for portability.

REPLACEMENT OF SAW BLADE

Detaching blade & Attaching blade



- Loosen the screw with coin or screwdriver, and pull the blade out from the handle.
- Insert the blade, and tighten the screw to fix the blade firmly.

CAUTION:

Since the saw teeth are very sharp, we recommend that you wear gloves or wrap the blade with something (a cloth or towel or its cardboard sleeve) when replacing the blade.